

Q324 User Guide

www.micromaxinfo.com

Content	
Your Device OS.....	1
Read Me First.....	1
Disclaimer.....	1
Understand Your Phone.....	3
Getting Started.....	3
SIM and Memory Card Insertion.....	3
Handset Keys.....	5
Power Key.....	5
Volume Keys.....	5
Navigation Keys.....	6
Charge the Battery.....	7
Home Screen.....	8
Application Launcher.....	8
Account Configuration.....	9
Google Account.....	9
Other Accounts.....	9
Notifications.....	10
Gravity Sensor.....	11
Phone Security.....	12
Unlock the Screen.....	12
Phone Unlocking Methods.....	12
Google Search.....	14
Using the Touch Screen.....	14
Tap and Hold.....	14
Drag an Item.....	14
Scroll.....	15
Swipe.....	15
Using the Pinch Zoom.....	15

Double-tap.....	16
Using the Onscreen Keyboard.....	16
Recent Applications.....	17
Make a Call.....	17
Video Call.....	19
Contacts.....	19
Synchronize Your Contact List.....	20
Airplane Mode.....	20
Send Message.....	21
Power Key.....	21
FM Radio.....	21
Camera.....	22
Navigation Keys.....	22
Gallery.....	23
Music Player.....	23
Settings, Networks, & Applications.....	24
Connect to the Internet.....	24
Tethering & Portability.....	24
Pair With Bluetooth Devices.....	26
Google Maps.....	26
Manage Applications.....	27
Safety Precautions.....	28
Taking Care of Your Device.....	30
Battery Recommendations.....	30
Recycle your Phone.....	31
Copyright.....	31

Your Device's OS

Micromax Q324 comes with KITKAT 4.4.3 that is capable of performing various functions just like your personal computer and can be personalized according to your own needs. For example, you can add and remove applications or upgrade existing applications to improve the functions. At the Google Play Store, an ever-growing range of applications, games, movies, and books are available for you to download.

Read Me First

- Please read all safety precautions and this manual carefully before using your device to ensure safe and proper use.
- The descriptions in this manual are based on the default settings of your device.
- Available features and additional services may vary by device, software, or service provider.
- Applications and their functions may vary based on the country, region, software, or hardware specifications. Micromax is not liable for performance issues caused by third-party applications.

Disclaimer

- The colors, specifications, functions and graphics shown/mentioned in the user manual may differ from the actual product. In such a case, the latter shall govern. Images shown are for representation purpose only. Specifications are subject to change without prior notice. Micromax keeps the right to modify the content in this user guide without prior notice.
- Upon first use of your device, your device will send information related to your mobile, IMEI numbers, location details and other software details through SMS* automatically. This information may be used as further specified in Micromax privacy policy**.
- Talk and standby times are affected by network preferences, type of SIM cards, connected accessories and individual usage patterns. Services and some features may be dependent on the network, service/content providers, SIM cards, compatibility of the devices used

* and the content formats supported.
Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
*Operator tariff shall be applicable for SMS.
**Micromax privacy policy is available at www.micromaxinfo.com.

Understand Your Phone

Getting Started

SIM and Memory Card Insertion

Your Q324 is a dual SIM phone with expandable memory. Switch off your phone before SIM/memory card insertion/removal and insert the card(s) in the slots correctly.

- Remove the battery (if inserted).
- Your Device is supports one Normal SIM and Micro SIM. Insert the SIM card(s) in the respective SIM slot(s) as indicated below.
- Insert the memory card in the memory card slot.
- Please keep the SIM Card out of the reach of children.

Handset Keys

Power Key

- Turn On:** Press the Power key for 3-4 seconds.
- Wake up the Screen:** Firmly press the Power key to wake up the screen or to turn off the screen.
- Turn Off:** Wake up the screen first. Now, long press the Power key then tap "Power off" to turn off the phone.
- Quick Options:** Wake up the screen first. Now, press the Power key for 2 seconds to view quick options to turn off the phone, reboot, switch to airplane mode, or adjust the sound profiles.

Volume Keys

Adjust the in-call, media, and ringtone volume from the volume keys available on the left side of the device.

Handset Keys

Menu Key

- Opens a menu with items that affect the current screen or application.
- While you are on the home screen, tap to view quick access options.
- Long tap to open the most recently used applications.

Home Key

- Opens the Home screen. If you are viewing any of the extended Home screens, opens the central Home screen.
- Long tap to open Google Now.

Back Key

- Takes you to the previously opened screen until the Home screen appears.
- If the onscreen keyboard is open, closes the keyboard.

Charge the Battery

Before using the device for the first time, we recommend you to use the power adapter to charge the battery for atleast 1-2 hours.

Connect the power adapter to the power outlet and the USB cable, as illustrated below.

When turned on, the battery level and charging status gets displayed in the upper-right corner of the screen.

Use only Micromax chargers and cables. Other chargers or cables can cause the battery to explode or damage your device. This may invalidate your phone warranty.

Home Screen

You can personalize your home screen with shortcuts, widgets, and wallpapers. To view quick options to change wallpaper, add widgets, or open settings section, tap the key. You can add extensions to the home screen by dragging an item to the right edge of the screen until a new screen appears. Your Q324 will show only those extended home screens that have some shortcut/widget placed on them. Swipe left or right on the home screen to view the next extended home screen.

In the bottom pane, there will be five launcher icons for you to open different sections in the phone. Except the application launcher in the middle, you can rearrange and manage the other four icons. Tap and hold to select a launcher icon and then you can rearrange, change, or remove them with ease.

Know More About Widgets...

Widgets allow placing application shortcuts on your home screen. You can place analog clock, your recent call logs, and other such sections of your phone on the home page and access them directly. View all available widgets by tapping the key and then tapping **Widgets**.

Application Launcher

Application launcher can be accessed from the quick launch menu as shown below.

Tap to view all inbuilt and installed applications. In the application menu, tap and hold any application to take it to the home screen; release the hold to place at any desired location on the home screen.

Account Configuration

Google Account

Some applications and services of your smartphone may require you to sign in to your Gmail account or create a new one.

Configuring Gmail account will not only allow you to access your emails but will also enable you to sync your phone calendar and contacts with your Gmail account. Changing your handset and taking contact list backup cannot get easier. In addition to this, your Gmail account lets you take full advantage of applications and services offered by Google on your Android phone. Configure your Google account on this handset to get an ease-of-access and sync your preferences and data on some applications rendered by Google.

Network connection is required for a successful Gmail account configuration.

Other Accounts

In addition to Gmail, you can configure other email accounts from:

→ → **Add account**

Also, you can download desired email application from the Play Store and access emails from the respective application.

Notifications

Your phone notifications you of events and messages as and when they occur. You can handle the notification interface as depicted below:

Open Notification Panel

Close Notification Panel

When you receive a notification, its icon appears in the status bar, along with a brief summary. You may clear each notification separately by swiping it towards left or right.

Toolkit provides you shortcuts to manage basic phone features, such as Airplane Mode, Wi-Fi, Display Brightness, and many more.

Open Toolkit Quick Access Panel

Gravity Sensor

Your phone has gravity sensor to detect its orientation and adjust the display (auto-rotate) based on the motion.

You can enable/disable the auto-rotate feature by dragging down the notification panel, tapping , and then selecting **AUTO ROTATION**. Or, you can enable/disable the auto-rotate feature from: → **Display** → **Auto-rotate screen**.

Phone Security

Unlock the Screen

By default, Slide Unlock is your unlocking technique.

To unlock:

- Wake up the screen by firmly pressing the Power key.
- Place your finger on the lock icon and drag it towards the unlock icon to unlock the screen.

Protect your phone from unauthorized access. Once locked, the phone can be unlocked by providing the unlocking password set while choosing the unlocking technique.

Phone Unlocking Methods

Choose and set a screen unlocking technique from:

→ → **Security** → **Screen lock**

It is important to remember the passwords and commands, which you set for your phone.

Slide Unlock

Place your finger on the lock icon and drag towards the unlock icon.

Pattern

Connect the dots to form a pattern and use the same to unlock.

PIN

Set a PIN of atleast four digits as the password to unlock.

Password

Set and use an alphanumeric password of atleast 4 characters to unlock the phone.

Google Search

Search anything in your phone or the outside world from Google Search. You can type your search keywords or can even speak it up as your search supports voice recognition also. Use voice commands to access various useful sections on your handset.

Google Search is available on the home screen and in the application menu too.

Using the Touch Screen

Tap and Hold

Tap and hold an item to view the list of actions based on the selected item and condition. Also, you can move an item from the Apps screen to the home screen.

Drag an Item

Tap and hold an item and move your finger on the screen until you reach the target position.

Scroll

To scroll a list, slide your finger across the surface of the screen upwards or downwards.

Double-Tap

Tap quickly twice on a webpage, map, or other screen to zoom. For example, double-tap a section of a webpage in the browser to zoom that section.

Swipe

Place a finger on the screen and steadily slide your finger in the desired direction.

Using the Onscreen Keyboard

Some applications display the keyboard by default. In others, you will be required to tap a text field, where you want to enter text, to open the keyboard.

Using the Pinch Zoom

You can open any image or web page and then use your thumb and index finger to zoom the display through the pinch gesture.